Stretching Fence Fabric

Insert a tension bar about 3' inside the unattached end of the fabric. Then securely fasten one end of a fence stretcher to this bar; the other end to the terminal post. Stretch fabric until it becomes taut. To judge proper tension, squeeze the diamonds formed by the wire with your hands. Fabric tension is sufficient is a slack is created. Then insert a tension bar and connect to tension bands on terminal post. After removing the fence stretcher, fasten fabric securely with the tie wires spaced approximately 24" apart along the top rail and 12" apart on each line post. Finally, securely tighten nuts on all brace and tension bands.

